

SET UP GUIDE

Satellite subscription



Cellular subscription



STEP 1

Create account

If you bought your Agbot at www.agbot.tech, you do not need to complete this step.

STEP 2

Download app

Sign in using the credentials that you created during the account and subscription setup.

STEP 3

Installation

Watch the video and follow the steps below.



Step 1 & 2 require access to wifi or mobile data. Once activated your Agbot will only use a satellite or cellular connection. Remove your phone case or any magnets as these will interfere with the NFC activation. Scan the QR code for a list of NFC compatible phones.

1




On the Inventory Page, select the + "Add Device" and select an "Asset Type".

2




From the dropdown menu select "Sensor Type & Length" and tap "Next".

3



Select the tank orientation Vertical, Horizontal or Square.

4




Enter the asset dimensions for height (Depth) to the overflow and Diameter in Meters, then the Total Volume in Litres.

5



Name your Asset e.g. "Workshop Diesel Tank". Tap "Next".

6



Select "Start", place your phone flat on the QR Code/ NFC Icon on the left side of the Agbot for **approx. 1 minute**. You will feel a vibration when the NFC connection is made **do not move your phone**. iPhone users will see several pop-ups at the base of the screen - **do not move your phone**. until you see the message '**Device NFC Operation Succeeded**'. Next, you will be prompted to take a photo of the tank.

7



8



Attach the sensor cable to the device by lining up the white dots, push firmly, then rotate the lock nut clockwise until it cannot rotate further. **Note: Test it is affixed properly by pulling on the cable.**

9



Clip on the protective cover to the Agbot by hooking in the antenna side first. **Note: the O-ring is not required unless you are fitting the Agbot into a 2" BSP point.**

10



Climb the tank, taking the activated Agbot, parts and necessary tools.

11




Climb the tank, taking the activated Agbot. Drill hole above overflow level. Ensure the hole is clean, deburred and will not damage the cable.

12



Line up the drilled hole with the mounting bracket and secure it with the screws.

13



Place the nut into the mounting bracket, then lower the sensor cable to the bottom of the tank.

14



Place the device onto the bracket, using the nut to tighten firmly into position.

15



The installation is now complete. Agbot Satellite will take 24-72 hours for its first reading.



- NFC compatible smartphone or device
- Cordless drill
- 1 inch hole saw
- 4 x 12g tech screws
- Measuring tape
- Ladder
- Additional tools may be required

